




### Operating Instructions:

- 1. Push down on the platform  
(wheels will automatically unfold)
- 2. Squeeze the handle and the release bar and extend to one of 3x height options.
- 3. To fold, push the support leg to release the lock  
(wheels and platform will fold together)
- 4. Fold the platform securely to the frame  
(wheels will automatically fold)



#### Moving Up Stairs:

Hold handle securely  
Incline cart to balance load  
Pull behind as you walk

#### Moving Down Stairs:

Hold handle securely with cart in front  
Follow cart down stairs  
NOTE: You must control rate of descent

#### Open Dimensions:

43.9" H x 23" W x 19.5" L  
(1115mm H x 584mm W x 495mm L)

[www.UpCart.com](http://www.UpCart.com)

#### Folded Dimensions:

21.2" H x 24.3" W x 4.4" L  
(546mm H x 617mm W x 112mm L)

**CAUTION:** For your safety, do not exceed the load weight of 100lbs/45.5kg.



Do not load goods when cart is inclined.



Be sure no one is beneath you on stairs.



Never hold or lift by release bar.



Never let go of cart when on stairs



Be sure to secure the load to the frame



[www.UpCart.com](http://www.UpCart.com)  
800-539-3653

Net Wt. 9.7lb/  
4.4kg



UP FOR ANYTHING!

## All-Terrain Stair Climber

For Indoor/Outdoor Use  
Holds up to 100lbs/45.5kg.

- Reduced Effort Up And Down Stairs
- Improved Stability And Balance
- Enhanced 3-Position Handle

Perfect For Moving Or On The Go!



UP FOR ANYTHING!