

MEASURE KING™

3-In-1 Digital Tape Measure




PRODUCT GUIDE

GETTING STARTED:

Thank you for your purchase of Measure King™ - the world's best 3-in-1 tape measure! Measure King™ offers three different modes: **Cord Mode** works similar to a tape measure, **Roller Mode** measures curves and objects by rolling along them, and **Laser Mode** measure objects or surfaces that are long and out of reach.

BATTERIES:

1. Remove the screws from the back and place cover aside.
2. Install 4 x AAA batteries as shown in compartment.
3. Replace cover and screw back into place.



SETUP:


Press POWER button to turn Measure King™ on. Then, choose measurement unit by pressing MODE/SAVE and CLEAR/< > buttons at the same time. You can choose from :

Feet and inches with fractions	
Inches with fractions	
Inches with decimals	
Centimeters with decimals	

Measure King™ display will dim after a few seconds of inactivity. To power off, hold the POWER/MEMORY button for 2 seconds.

GETTING STARTED (CONT.):

DISPLAY & BUTTONS:



WARNINGS:

Remove old batteries and replace with new batteries. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Rechargeable batteries must be removed before being recharged. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be charged only under adult supervision. Use 1.5V AAA Batteries or equivalent only. Do not short-circuit battery terminals. Always remove weak or dead batteries from product. Remove batteries if product will be stored for an extended period of time. Batteries should be changed by an Adult. Be sure to insert batteries correctly according to (+) and (-) symbols located on the battery compartment.

WARNING: Battery acid and leakage can cause personal injury and cause damage to your Measure King™ product and surrounding property. If battery leakage occurs, thoroughly wash any affected skin, making sure to keep battery acid away from eyes, ears, nose and mouth. Immediately wash any clothing or other surface that comes into contact with leaked battery acid. Leaking batteries may make "popping" sounds.

- Use of controls or performance of procedures other than those specified herein may result in injury.
- Do NOT stare directly at the laser beam.
- Do NOT project the laser beam directly into the eyes of others/ animals.
- Do NOT set up the tool at eye level or operate the tool on or near a reflective surface, as the laser beam could be projected into your eyes or eyes of others.

CORD MODE:


✓ BEST FOR:

Flat surfaces - Round Surfaces - Body Measurements

📖 HOW TO:

Press the MODE/SAVE button until the Cord Mode icon  shows.

Pull out the cord to the length needed to measure your surface or object. Check the display for your measurement. Retract cord in a controlled speed to ensure it returns to the unit properly.



💡 TIPS:

Hold Mode: If you need your measurement to stay on the screen after cord has retracted, press the MEASURE button to enable to Hold function before you start. **H** will appear when Hold Mode is enabled.

Zero Out: If your Measure King™ does not start from zero, press the CLEAR/< > button to zero out the measurement before using.


Start Position: Hold the CLEAR/< > button for 2 seconds to choose if your measurement starts from the front (cord side) or back (roller side) of the unit. If you choose to start from the back side, 3.5 inches will be added onto your measurement automatically to include the length of Measure King™.

LASER MODE:


✓ BEST FOR:

Walls - Ceilings - Hard To Reach Areas, Up to 25 feet

📖 HOW TO:

Press the MODE/SAVE button until the Laser Mode icon  shows.

Point Measure King™ towards the object or surface you want to measure. Press the MEASURE button and use the built-in laser pointer to place your measurement.



💡 TIPS:

Best Use: Hold Measure King™ in an upright position to simulate a flat surface. It is best to stand directly in front of the object or surface you want to measure. This will help you get the most accurate measurement possible.


Start Position: Hold the CLEAR/< > button for 2 seconds to choose if your measurement starts from the front (cord side) or back (roller side) of the unit. If you choose to start from the back side, 3.5 inches will be added onto your measurement automatically to include the length of Measure King™.

ROLLER MODE:


✓ BEST FOR:

Curved Objects - Irregular Shapes - Long Flat Surfaces

📖 HOW TO:

Press the MODE/SAVE button until the Roller Mode icon  shows.

Hold the MEASURE button and roll Measure King™ along the object or surface you would like to measure. Release the MEASURE button when done and check your measurement on the display.



💡 TIPS:


Forward/Backwards: You can roll both forward and backwards while in roller mode. If you have gone too far, continue to hold the MEASURE button, and roll in the opposite direction.

Pause/Restart: You can begin a measurement, pause, and re-start again. Just hold the Measure button, release to pause, and repeat until entire measurement is complete.

SAVING MEASUREMENTS:

SAVE:

In any mode, while your measurement is displayed, hold the MODE/SAVE button for 2 seconds. "M" icon will blink. The most recent saved measurement will be placed in the M1 position.



REVIEW:

Press the POWER/MEMORY button to view your saved measurements. Your most recent measurement will show first (M1). Press the POWER/MEMORY button again to cycle through all of your saved measurements.



DELETE:

Press the POWER/MEMORY button until you find the measurement you would like to delete. Hold the CLEAR/< > button for 2 seconds. All measurements will now move up to the next available position. For example, if M3 is deleted, M4 will move to M3 position, M5 will move to M4 position and so-on.

